ACCUSPLIT® AX605
OPERATING INSTRUCTIONS

Twin Button Feature:
The Left and Right buttons on new ACCUSPLIT stopwatches operate interchangeably, so both are labeled **"A"** for these instructions.

Event
A – Start
A – Stop ("Time Out")
A – Restart ("Time In")
A – Stop
C – Reset

BATTERY CHANGING
If the display becomes dim or goes blank, you can replace the battery using "X3V" case battery changing instructions posted at www.accusplit.com/support. The watch uses a five-year CR2032 Lithium battery.

Master Reset
Remove battery as shown above. Wait 5 seconds and reinstall.

NO-PROOF-OF-PURCHASE LIMITED WARRANTY
See label on back of unit for details, or check
http://support.ACCUSPLIT.com

ACCUSPLIT, Inc. • 3090 Independence Drive, Suite 148 • Livermore, CA 94551 USA
800-935-1996 • 925-290-1900 • FAX 925-290-1930
www.ACCUSPLIT.com • support@ACCUSPLIT.com

Downloaded from www.Manualslib.com manuals search engine